MAAS RADIATOR, INC.
Complete Cooling System Sales & Service
(877) 348-3888

HOW TO MEASURE A CHARGE AIR COOLER CORE

Although a charge air cooler core resembles a radiator core, they are measured differently. A charge air cooler core's **width** is the space between the tanks from header plate to header plate. The **height** is the direct top of the coolers core to the direct bottom of the core

Three specific measurements are needed to ensure the correct size of the charge air cooler: height, width and thickness. The thickness is also known as the depth. Accurate information will be needed when a charge air cooler is going to be recored.